

**THINGS TO CONSIDER BEFORE YOU BEGIN:** 1: Radio signals between the coordinator and the swipers can easily travel through non-metal walls, but cannot travel through metal plates or large metal objects like metal walls, roofs, pumps, control boxes, or water tanks. 2: If you are using a Wi-Fi network on your site, separate the wireless router's antenna from the CryptoPay coordinator's antenna by at least 6 feet. This will prevent radio interference.

- 1 Coordinator installation** – install the coordinator at the location where you are installing CryptoPay, near an electrical outlet and the internet connection.
- 2 Power Cord** – plug in the supplied power cord to coordinator and into wall outlet.
- 3 Internet Cable** – plug in the internet cable to the coordinator and into your router box.
- 4 Antenna** – attach the supplied antenna to the coordinator. The antenna should be in a vertical position as shown in the picture.
- 5 Run Light** – A solid run light lets you know the coordinator has power. This light will begin to flash when the coordinator detects an internet connection.
- 6 Configure Coordinator** – Remember, you will need the coordinator's CPY number (located on top outer edge). Move on to the next section of the CryptoPay Quick Start Guide: **Online Configuration**.

